

JetPort Kayak Launch

Grab Bar and Overhead Bar Installation Instructions

Included in Kit:

- 1 - Overhead Bar
- 2 – 10' Grab Bars with Plastic End Caps
- 2 – Connector “T” s with Allen Head Set Screws
- 2 - 4-1/2” x 1/4” Bolts with 1/4” Washer, Lock Nut and Cap Nut

Required Tools:

- 3/16” Allen Wrench
- 1/2” Wrench

Installation Instructions: (Reference image below)

1. Slide Grab Bar open ends through back openings in Kayak Launch about half-way in.
2. Slide one (1) Connector “T” over each Grab Bar with Setscrews facing outwards from the open pipe end – Do not tighten yet.
3. Slide both Grab Bars forward into the front Grab Bar slot keeping in mind the alignment of the holes in the Grab Bar which align with the holes in the “Launch End” Grab Bar Holder.
4. From the inside of the Kayak Launch, secure the Grab Bars with the supplied 4 1/2" Bolts, washers, lock nut, then cap nut.
5. Place the open ends of the Overhead Bar securely into each Connector “T”. Tighten the top Set Screw only.
6. Determine the optimal desired location and adjust the position of the Overhead Bar. Tighten the bottom set screw to finalize the installation.
7. Maintain a “like new” appearance by cleaning with a mild marine grade aluminum product.

